

Maintenance and care of lacquered surfaces



Regular damp mopping

With the *Ecoline Wash Care* normal dirt can be removed mildly, thoroughly and streak-free from all washable surfaces.

Dilute *Ecoline Wash Care* concentrate with water (approx. 3 caps per 5 liter water). Make sure that the wiping cloth is wrung out carefully to ensure damp cleaning. Wipe dry if necessary.

Perfect combination:

Ecoline Maintenance-Set and
Ecoline Wash Care

Frequency of use:

Weekly (in objects) or whenever needed



Refreshing care & maintenance

Always use the *Ecoline Wash Care* before applying the *Ecoline Refresher*.

For an effortless refreshing of all lacquered surfaces just dilute 1:10 with water (0,5 L *Ecoline Refresher* with 5 L water) and with a well wrung-out mop spread evenly on the surface. Wipe dry if necessary.

Frequency of use:

Monthly (in objects), 2 x per year or whenever needed



Intensive cleaning

Ecoline Magic Cleaner cleans fast and intensive all dirty surfaces.

Dilute 1:10 with water and spread evenly either with a cloth or mop. Allow to absorb for 5 – 20 minutes. The loosened dirt can be collected with either cloth or mop.

Then damp mop 2 – 3 times with clear water until it is clean. Wipe dry. After complete drying, maintain with *Ecoline Refresher*.

Frequency of use:

2 times per year (in objects) or whenever needed

Basic rules apply for all wood floors:

- The wood floor should be dry-cleaned on a regular basis. Refrain from using microfiber and use a parquet nozzle while vacuum cleaning in order to avoid scratch marks.
- For a healthy indoor climate and for the conservation of value we recommend a room temperature of 20 – 25 °C as well as an air humidity of 55 – 60%.
- Pay attention that chairs with bottom rollers are suitable for parquet. Protect the floor with mats. Put felt pads under the chair leg in order to avoid scratch marks.
- We recommend dirt traps, e.g. door scrapers or carpet areas at the entrance as sharp-edged dirt like sand can damage every floor.
- Protect your wood floor from water (e.g. wetness due to leaking flower pots or vases).
- Refrain from using objects that bottom side is either made of rubber or latex (e.g. door stopper). The containing substances (softening agents) may cause dirt spots.

You will realize that your treated and maintained floor will become low-maintenance over time.